







































































Original	Replacement	Original	Replacement
 Power	 Power	 Menu	 Menu / Home
 Mute	 Mute / Dimmer	 Vol-	 Vol-
 1	 1	 Left	 Left
 2	 2	 OK/List	 OK
 3	 3	 Right	 Right
 4	 4	 Vol+	 Vol+
 5	 5	 Info	 Info / Angle
 6	 6	 PR-	 CH- / Page-
 7	 7	 Down	 Down
 8	 8	 Exit	 Exit / Cancel / Clear
 9	 9	 Red	 Red / Netflix / Search
 Tv/Radio	 TV/Radio /	 Audio	 Audio / Lang I/II
 0	 0	 ↑	 >> / Tune+
 ←PR	 Back / Return	 Yellow	 Yellow / YouTube / Repeat
 EPG	 Guide / EPG / -/--	 [...]	 Subtitle / EQ
 Up	 Up	 ↓	 << / Tune-
 PR+	 CH+ / Page+	 Blue	 Blue / Prime Video / Random



