Mandis shop

LG AKB36086232

Original	Replacement	Original	Replacement
Power	Power	Stop	OK
EQ	Subtitle / EQ	Stop	Stop / Hold
Preset/Folder+	CH- / Page-	>> / >>I /	>>I / Preset+
Preset/Folder+	Shift + >>I / Preset+	>> / >>I /	>> / Tune+
Function	Menu / Home	>> / >>I /	Right
Volume+	Vol +	Program/Memo	Fav / Marker / PC
Preset/Folder-	CH+ / Page+	Program/Memo	TV/Radio /
Preset/Folder-	Shift + I<< / Preset-	Play / Pause	Play / Slow
Mute	Mute / Dimmer	Play / Pause	Down
Volume-	Vol -	Play / Pause	Pause / Step / Freeze
Repeat /	Green / APP / Repeat	Rec	Rec / Rec Mode
Repeat /	Blue / Prime Video / Random	RDS	Display / Media
Repeat /	Up	PTY	Smart / List
Info	Info / Angle		
<< / I<< / Tun	I<< / Preset-		
<< / I<< / Tun	<< / Tune-		
<< / I<< / Tun	Left		

https://remotes.at/en/LG-AKB36086232-replacement-remote-control-for-LG-AKB36086232.htm