






















































Original	Replacement
 Power	 Power
 TV/SAT	 Smart
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 SAT	 Media
 FAV	 Pre Ch
 Menu	 Menu
 EPG	 Guide

Original	Replacement
 Recall	 Back
 Exit	 Exit
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol+	 Vol +
 Vol-	 Vol -
 CH&Page+	 Ch +
 CH&Page-	 Ch -
 Red / TTX	 Red
 Red / TTX	 Text
 Green / Sub.T	 Green
 Green / Sub.T	 Subt
 Yellow / Zoom	 Yellow
 Yellow / Zoom	 Eject





Original	Replacement	Original	Replacement
 MP	Blue / MP	 D	Blue
 TV/RADIO	TV/Radio	 SEARCH TV/R	TV/R
 AUDIO	Audio	 SOUND DUAL	Dual
 PAUSE	Pause		Pause
 POS	POS	 PICTURE FORMAT	Format
 REC	Rec		Rec
 INFO	Info		Info
 P/N	P/N	 ECO 3D	3D
 T/S	T/S		AV

