









Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	Audio		Dual
	Sub-T		Subt
	Info		Info
	Tv/Radio		TV/R
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	PgUp		Ch +
	PgDn		Ch -
	Menu		Menu
	Exit		Exit
	Play		Play
	Pause/Timeshift		Pause
	<<		<<
	>>		>>
	I<<		I<<
	>>I		>>I
	OK		Ok
	Up/CH+		Up
	Down/CH-		Down
	Vol+		Vol +
	Right		Right
	Left		Left
	Vol-		Vol -
	Goto		Back





Original	Replacement	Original	Replacement
 Rec	 Rec		
 Stop	 Stop		
 Slide Show	 AV		
 DVB-T	 Smart		
 EPG	 Guide		
 TTX	 Text		
 FAV	 Pre Ch		
 Setup	 Options		
 Repeat	 Shift + Text		
 TV System	 Format		
 Zoom	 Eject		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

