



Original	Replacement	Original	Replacement
Power	Power	Blue/[ ]	Blue
Vol+	Vol +	Info	Info
Vol-	Vol -	Text	Text
PR+	Ch +	1	1
PR-	Ch -	2	2
Mute	Mute	3	3
Menu	Menu	4	4
Exit	Exit	5	5
Back	Back	6	6
OK	Ok	7	7
Up	Up	8	8
Down	Down	9	9
Right/Zoom+	Right	0/-/--	0
Left/Zoom-	Left	AV	AV
Red/[o]	Red	SP/LP	Media
Green/Timer/List	Green	Play	Play
Yellow	Yellow	>>	>>





	Original	Replacement		Original	Replacement
	<<	 <<			
	Stop	 Stop			
	Pause	 Pause			
	Rec	 Rec			
	Mark	 3D			
	0000	 GUIDE			

	Original	Replacement		Original	Replacement











Original	Replacement	Original	Replacement
Power	Power	Blue/[ ]	Blue
Vol+	Vol +	Info	Info
Vol-	Vol -	Text	Text
Mute	Mute	Play	Play
PR+	Ch +	Stop	Stop
PR-	Ch -	Rec	Rec
Exit	Exit	Pause	Pause
Menu	Menu	>>	>>
Back	Back	<<	<<
Up	Up	1	1
Down	Down	2	2
Right/Zoom+	Right	3	3
Left/Zoom-	Left	4	4
OK	Ok	5	5
Red/[o]	Red	6	6
Green/Timer/List	Green	7	7
Yellow	Yellow	8	8





Original	Replacement	Original	Replacement
 9	 9		
 AV	 AV		
 SP/LP	 Media		

















Original	Replacement	Original	Replacement
	Power		Blue/[ ]
	Vol +		Info
	Vol -		Text
	Mute		1
	Ch +		2
	Ch -		3
	Menu		4
	Exit		5
	Back		6
	Up		7
	Down		8
	Right		9
	Left		0
	Ok		AV
	Red		Media
	Green		Play
	Yellow		Stop





	Original	Replacement	Original	Replacement
	>>	 >>		
	<<	 <<		
	Rec	 Rec		
	Pause	 Pause		
	Mark	 3D		
	0000	 GUIDE		

