








































































Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Recall		Back
	Vol +		Vol +
	Vol -		Vol -
	Input		AV
	List		List
	PR +		Ch +
	PR -		Ch -
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Menu		Menu
	Exit		Exit
	FAV		Pre Ch
	EPG		Guide
	TV		TV/R
	I / II		Dual
	PSM		Format
	SSM	 + 	Shift + Dual
	ARC		Options





	Original	Replacement		Original	Replacement
	Sleep	 Sleep			
	Text	 Text			
	Size	 Eject			
	Reveal	 Smart			
	Page +	 Shift + Ch +			
	Page -	 Shift + Ch -			
	Index	 Shift + Info			
	Hold	 Stop			
	S.Page	 Subt			
	Red	 Red			
	Green	 Green			
	Yellow	 Yellow			
	Blue	 Blue			

