



	Original	Replacement	Original	Replacement
	Program	 TV/Radio /		
	-10	 Guide / EPG / -/--		
	+10	 Fav / Marker / PC		
	Play	 Play / Slow		
	Pause	 Pause / Step / Freeze		
	<<	 << / Tune-		
	<<	 << / Preset-		
	>>	 >> / Tune+		
	>>	 >> / Preset+		
	Stop	 Stop / Hold		
	Repeat	 Green / APP / Repeat		
	Vol-	 Vol-		
	Vol+	 Vol+		

