




| Original | Replacement |
|---|--|
|  Power |  Power |
|  P.Mode |  Shift + Format |
|  S.Mode |  Shift + Dual |
|  I / II |  Dual |
|  Sleep |  Sleep |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  CH.List |  List |
|  Recall |  Back |

| Original | Replacement |
|--|--|
|  Source |  AV |
|  Menu |  Menu |
|  Up |  Up |
|  Right |  Right |
|  Down |  Down |
|  Left |  Left |
|  OK |  Ok |
|  Info |  Info |
|  Exit |  Exit |
|  Vol + |  Vol + |
|  Vol - |  Vol - |
|  Mute |  Mute |
|  Aspect |  Format |
|  CH + |  Ch + |
|  CH - |  Ch - |
|  Play/Pause / EPG |  Guide |
|  Play/Pause / EPG |  Play |





| Original | | Replacement | | Original | | Replacement | |
|---|------------------|---|--------------|---|--------|---|--------|
|  | Play/Pause / EPG |  | Pause |  | Green |  | Green |
|  | Stop / Fav |  | Pre Ch |  | Yellow |  | Yellow |
|  | Stop / Fav |  | Stop |  | Blue |  | Blue |
|  | Add / Del |  | TV/R | | | | |
|  | Media |  | Media | | | | |
|  | I<< / TTX |  | Text | | | | |
|  | I<< / TTX |  | I<< | | | | |
|  | << / Cancel |  | << | | | | |
|  | << / Cancel |  | Shift + Exit | | | | |
|  | Size |  | Eject | | | | |
|  | Subtitle |  | Subt | | | | |
|  | >>I / Hold |  | >>I | | | | |
|  | >>I / Hold |  | Shift + Stop | | | | |
|  | >> / Reveal |  | >> | | | | |
|  | Subpage |  | Shift + Subt | | | | |
|  | Index |  | Shift + Info | | | | |
|  | Red |  | Red | | | | |

