







































































Original		Replacement		Original		Replacement	
	POWER		Power		TEXT		Text
	SOURCE		AV		0		0
	ASPECT		Format		RECALL		Back
	MENU		Menu		TV		TV/R
	S.MODE		Shift + Dual		∧		Up
	P.MODE		Shift + Format		>		Right
	1		1		V		Down
	2		2		<		Left
	3		3		MENU		Ok
	MUTE		Mute		VOL+		Vol +
	4		4		VOL-		Vol -
	5		5		CH-		Ch -
	6		6		CH+		Ch +
	DISPLAY		Info		SLEEP		Sleep
	7		7		SUBCODE		Subt
	8		8		ZOOM		Eject
	9		9		STILL		Pause



