







































































Original		Replacement		Original		Replacement	
	Power Tv		Power		Mute		Mute
	Power STB		Shift + Power		P+		Ch +
	Source		AV		P-		Ch -
	1		1		CH List		List
	2		2		Menu		Menu
	3		3		Smart Hub		Smart
	4		4		Guide		Guide
	5		5		Tools		Options
	6		6		Info		Info
	7		7		Return		Back
	8		8		Exit		Exit
	9		9		Up		Up
	0		0		Down		Down
	TTX/MIX		Text		Right		Right
	PRE-CH		Pre Ch		Left		Left
	Vol+		Vol +		Enter		Ok
	Vol-		Vol -		Red		Red





Original	Replacement	Original	Replacement
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		
 Search	 TV/R		
 Status	 Media		
 More	 3D		
 E-Manual	 D. Menu		
 Recommend	 Format		
 AD/Subt	 Subt		
 >>	 >>		
 <<	 <<		
 >>I	 >>I		
 I<<	 I<<		
 Pause	 Pause		
 Rec	 Rec		
 Play	 Play		
 Stop	 Stop		

