



Original	Replacement
Standby	Power
On	AV / Input / RDS
Keystone	Audio / Lang I/II
Up	Up
Menu/Help	Menu / Home
Left	Left
Enter	OK
Right	Right
Return	Back / Return
Down	Down
Back	Fav / Marker / PC
Forward	>> / Tune+
Break Timer	Sleep / Timer
Freeze	Pause / Step / Freeze
Vol+	Vol+
Picture Mode	Picture / Format
AV Mute	Mute / Dimmer

Original	Replacement
Vol-	Vol-
Input 1	1
Input 2	2
Auto Sync	Guide / EPG / -/--
Input 3	3
Input 4	4
Resize	Zoom / Size

