











| Original   | Replacement   | Original  | Replacement  |
|--|---|---|--|
|  Power          |  Power   |  Time/Text   |  Text           |
|  1              |  1       |  Timer       |  Shift + AV     |
|  2              |  2       |  Tv/Video    |  TV/R           |
|  3              |  3       |  [...]       |  Subt           |
|  4              |  4       |  O)))        |  Dual           |
|  5              |  5       |  -/--/Clear  |  Guide          |
|  6              |  6       |  System Menu |  Menu           |
|  7              |  7       |  Title List  |  List           |
|  8              |  8       |  Timer List  |  Format         |
|  9             |  9      |  Menu       |  D. Menu       |
|  0            |  0     |  Top Menu  |  Shift + Menu |
|  PR+          |  Ch +  |  Eject     |  Eject        |
|  PR-          |  Ch -  |  Return    |  Back         |
|  Vol+         |  Vol + |  Tools     |  Options      |
|  Vol-         |  Vol - |  Enter     |  Ok           |
|  Input Select |  AV    |  Up        |  Up           |
|  Display      |  Info  |  Down      |  Down         |





| Original  | Replacement   | Original  | Replacement   |
|---|---------------|---|---------------|
|      | Right         |    | Right         |
|      | Left          |    | Left          |
|      | Play          |    | Play          |
|      | Stop          |    | Stop          |
|      | Pause         |    | Pause         |
|      | >>/I>         |    | >>            |
|      | <</<I         |    | <<            |
|      | >>I           |    | >>I           |
|      | I<<           |    | I<<           |
|      | →             |  +          | Shift + Right |
|     | ←             |  +        | Shift + Left  |
|    | Visual Search |    | Blue          |
|    | Set           |    | Pre Ch        |
|    | Sur           |    | Sleep         |
|    | Rec           |    | Rec           |
|    | Rec Pause     |  +      | Shift + Pause |
|    | Rec Stop      |  +      | Shift + Stop  |
|    | Rec Mode      |  +      | Shift + Rec   |
|    | Synchro Rec   |    | 3D            |
|    | Chapter Mark  |    | Red           |
|    | Mark Erase    |  +      | Shift + Eject |
|    | Camera        |    | Exit          |
|    | Progressive   |    | Green         |
|    | [+]           |    | Yellow        |
|    | Power Tv      |  +      | Shift + Power |
|    | HDD           |    | Smart         |
|    | DVD           |    | Media         |
|   | 1 Tv          |  +    | Shift + 1     |
|  | 2 Tv          |  +  | Shift + 2     |
|  | 3 Tv          |  +  | Shift + 3     |
|  | 4 Tv          |  +  | Shift + 4     |
|  | 5 Tv          |  +  | Shift + 5     |
|  | 6 Tv          |  +  | Shift + 6     |
|  | 7 Tv          |  +  | Shift + 7     |





