



	Original	Replacement		Original	Replacement
	Off		Power		Mega Xpand
	Mode		Format		Media
	Radio/Band		TV/R		Snooze
	Audio In		AV		
	I<</Tune-		I<<		
	Play		Play		
	Pause		Pause		
	>>I/Tune+		>>I		
	Preset+		Ch +		
	Preset-		Ch -		
	Up		Up		
	Down		Down		
	Vol+		Vol +		
	Vol-		Vol -		
	Menu		Menu		
	Enter		Ok		
	Mega Bass		Smart		

