Mandis shop

Sony RMT-463

Original		Replacement		Original	Replacement
	Power		Power		
	Counter Reset	APP MEDIA	Media		
	Goto Zero	HOME SMART	Smart		
	Rec	REC MODE	Rec		
	Pause		Pause		
	X2	PICTURE FORMAT	Format		
	II > Frame	PROG SLEEP	Sleep		
	X1/10	TIMER AV	AV		
	X1/5	ECO 3D	3D		
	Play	PLAY MODE	Play		
	Search >>		>>		
	<< Search		<<		
	FF >>		>>I		
	<< Rew		I <<		
	Stop		Stop		