







































































Original		Replacement		Original		Replacement	
	Power		Power		3		3
	Mute		Mute / Dimmer		4		4
	P.Mode		Picture / Format		5		5
	S.Mode		Sound / Title		6		6
	Pic. Size		Zoom / Size		7		7
	Play / Pause		Play / Slow		8		8
	Play / Pause		Pause / Step / Freeze		9		9
	<<		<< / Tune-		-/-		Shift + Guide / EPG / -/-
	>>		>> / Tune+		0		0
	Stop		Stop / Hold		Return		Back / Return
	I<<		I<< / Preset-		CH+		CH+ / Page+
	>>I		>>I / Preset+		Display		Display / Media
	Nicam / A2		Shift + Audio / Lang I/II		Vol+		Vol+
	Rec PVR		Rec / Rec Mode		CH-		CH- / Page-
	Media		Smart / List		EPG		Guide / EPG / -/-
	1		1		Vol-		Vol-
	2		2		TV Menu		Menu / Home





Original	Replacement
	Up
	Sleep / Timer
	Left
	OK
	Right
	AV / Input / RDS
	Down
	Exit / Cancel / Clear
	Text / Goto
	+  Shift + Stop /
	Info / Angle
	Subtitle / EQ
	Audio / Lang I/II
	+  Shift + Zoom /
	Eject / Surround
	D.Menu / Top
	Red / Netflix / Search

Original	Replacement
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Fav / Marker / PC
	+  Shift + Down
	+  Shift + Up
	TV/Radio /

