


























































































| Original   | Replacement   |
|--|---|
|  Power  |  Power                   |
|  Mute   |  Mute / Dimmer           |
|  1      |  1                       |
|  2      |  2                       |
|  3      |  3                       |
|  4      |  4                       |
|  5      |  5                       |
|  6      |  6                       |
|  7      |  7                       |
|  8      |  8                       |
|  9     |  9                      |
|  Fav  |  Fav / Marker / PC     |
|  0    |  0                     |
|  Back |  Back / Return         |
|  Menu |  Menu / Home           |
|  Exit |  Exit / Cancel / Clear |
|  Up   |  Up                    |

| Original  | Replacement  |
|---|--|
|  Left      |  Left               |
|  OK        |  OK                 |
|  Right     |  Right              |
|  Down      |  Down               |
|  Source    |  AV / Input / RDS   |
|  EPG       |  Guide / EPG / -/-- |
|  Audio     |  Audio / Lang I/II  |
|  P.Mode    |  Picture / Format   |
|  S.Mode    |  Sound / Title      |
|  P.Size    |  Zoom / Size        |
|  CH+      |  CH+ / Page+       |
|  Fav+    |  Shift + Up       |
|  Vol+    |  Vol+             |
|  CH-     |  CH- / Page-      |
|  Fav-    |  Shift + Down     |
|  Vol-    |  Vol-             |
|  Display |  Display / Media  |





| Original  | Replacement   | Original  | Replacement   |
|---|---|---|---|
|  Auto          |  Setup / OPT /             |  Usb / Media     |  Shift + 8                     |
|  Sleep         |  Sleep / Timer             |  Play / Pause    |  Play / Slow                   |
|  S.Title       |  Subtitle / EQ             |  Stop            |  Stop / Hold                   |
|  Freeze        |  Pause / Step / Freeze     |  Rec             |  Rec / Rec Mode                |
|  Text          |  Text / Goto               |  Red / Goto      |  Shift + Text /                |
|  Index         |  Info / Angle              |  Red / Goto      |  Red / Netflix / Search        |
|  Nicam         |  Shift + Audio / Lang I/II |  Green / Slow    |  Green / APP / Repeat          |
|  Radio         |  TV/Radio /                |  Green / Slow    |  Shift + Play /                |
|  Hold          |  Shift + Stop /            |  Yellow / Repeat |  Shift + Green / APP /         |
|  I<<           |  I<< / Preset-             |  Yellow / Repeat |  Yellow / YouTube / Repeat     |
|  Size        |  Shift + Zoom /          |  Blue / A-B    |  Blue / Prime Video / Random |
|  >>I         |  >>I / Preset+           |  Blue / A-B    |  Shift + Yellow / YouTube /  |
|  S.Page      |  Shift + Subtitle / EQ   |   |   |
|  <<          |  << / Tune-              |   |   |
|  Reveal      |  Eject / Surround        |   |   |
|  >>          |  >> / Tune+              |   |   |
|  Usb / Media |  Shift + Display / Media |   |   |

| Original  | Replacement   | Original  | Replacement  |
|---|---|---|--|
|  Usb / Media     |  Shift + 8                     |  Play / Pause    |  Play / Slow                  |
|  Stop            |  Stop / Hold                   |  Rec             |  Rec / Rec Mode               |
|  Red / Goto      |  Shift + Text /                |  Red / Goto      |  Red / Netflix / Search       |
|  Green / Slow    |  Green / APP / Repeat          |  Green / Slow    |  Shift + Play /               |
|  Yellow / Repeat |  Shift + Green / APP /         |  Yellow / Repeat |  Yellow / YouTube / Repeat    |
|  Blue / A-B    |  Blue / Prime Video / Random |  Blue / A-B    |  Shift + Yellow / YouTube / |

