










Original	Replacement
	Power
	Mute / Dimmer
	Red / Netflix / Search
	Display / Media
	Green / APP / Repeat
	TV/Radio /
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Smart / List
	Vol-
	I<< / Preset-
	>>I / Preset+
	Vol+
	D.Menu / Top
	CH+ / Page+
	Up
	Back / Return

Original	Replacement
	Left
	OK
	Right
	Menu / Home
	CH- / Page-
	Down
	Info / Angle
	1
	2
	3
	4
	5
	6
	7
	8
	9
	Guide / EPG / -/-





Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 Red / Media	 Red / Netflix / Search
 Red / Media	 Display / Media
 Green / TV	 Green / APP / Repeat
 Green / TV	 TV/Radio /
 Yellow / Web	 Yellow / YouTube / Repeat
 Blue / APP	 Blue / Prime Video / Random
 Blue / APP	 Smart / List
 Vol-	 Vol-
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 Vol+	 Vol+
 Home	 D.Menu / Top
 Up / CH+	 Up
 Up / CH+	 CH+ / Page+
 Return	 Back / Return

Original	Replacement
 Left	 Left
 OK	 OK
 Right	 Right
 Menu	 Menu / Home
 Down / CH-	 Down
 Down / CH-	 CH- / Page-
 Mouse	 Info / Angle
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 1/A/a	 Guide / EPG / -/-



