



































| Original   | Replacement  | Original   | Replacement   |
|--|--|--|---|
|  Power    |  Power                      |  Green  |  Green / APP / Repeat        |
|  Mute     |  Mute / Dimmer              |  Sub    |  Subtitle / EQ               |
|  Stop     |  Stop / Hold                |  Yellow |  Yellow / YouTube / Repeat   |
|  Play     |  Play / Slow                |  Sleep  |  Sleep / Timer               |
|  Pause    |  Pause / Step / Freeze      |  Blue   |  Blue / Prime Video / Random |
|  <<       |  << / Tune-                 |  Timer  |  Shift + Sleep / Timer       |
|  >>       |  >> / Tune+                 |  Menu   |  Menu / Home                 |
|  Rec      |  Rec / Rec Mode             |  i      |  Info / Angle                |
|  USB      |  Shift + 8                  |  Up     |  Up                          |
|  I<<      |  I<< / Preset-              |  Left   |  Left                        |
|  >>I      |  >>I / Preset+              |  OK     |  OK                          |
|  Help     |  Smart / List               |  Right  |  Right                       |
|  FAV     |  Shift + Fav / Marker / PC |  Exit  |  Exit / Cancel / Clear      |
|  Audio  |  Audio / Lang I/II        |  Down |  Down                      |
|  Option |  Setup / OPT /            |  Back |  Back / Return             |
|  Red    |  Red / Netflix / Search   |  Vol+ |  Vol+                      |
|  TTX    |  Text / Goto              |  EPG  |  Guide / EPG / -/-         |





| Original  |          | Replacement   |                      |
|---|----------|---|----------------------|
|    | CH+      |    | CH+ / Page+          |
|    | Vol-     |    | Vol-                 |
|    | List     |    | Shift + Smart / List |
|    | CH-      |    | CH- / Page-          |
|    | 1        |    | 1                    |
|    | 2        |    | 2                    |
|    | 3        |    | 3                    |
|    | 4        |    | 4                    |
|    | 5        |    | 5                    |
|    | 6        |    | 6                    |
|    | 7        |    | 7                    |
|   | 8        |   | 8                    |
|  | 9        |  | 9                    |
|  | Tv/Radio |  | TV/Radio /           |
|  | 0        |  | 0                    |
|  | Recall   |  | Fav / Marker / PC    |

| Original | Replacement |
|----------|-------------|
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |
|          |             |

