







































Original	Replacement
 Power	 Power
 Display	 Shift + Info
 Mute	 Mute
 Video	 Media
 Scart	 Shift + Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Subpage	 Guide
 Pre-Ch	 Pre Ch

Original	Replacement
 Source	 AV
 PIP	 3D
 TV	 TV/R
 PC	 Shift + TV/R
 Sound	 Dual
 Sleep	 Sleep
 Swap	 Back
 Zoom -	 Shift + Left
 Zoom +	 Shift + Right
 Vol +	 Vol +
 Vol -	 Vol -
 CH +	 Ch +
 CH -	 Ch -
 Menu	 Menu
 Exit	 Exit
 Up	 Up
 Down	 Down





Original		Replacement		Original		Replacement	
	Right		Right				
	Left		Left				
	OK		Ok				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	Teletext		Text				
	Mix		List				
	Size		Format				
	Info		Info				
	Index		Options				
	Subtitle		Subt				
	Hold		Pause				
	Reveal		D. Menu				

