| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| SOURCE | Source | RDS AV INPUT | AV / Input / RDS |
| | Power | | Power |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| EPG | EPG | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI - SAT 0 | 0 |
| PRE CH | PRE-CH | RETURN BACK | Back / Return |
| HDMI | HDMI | SHIFT + HDMI - SAT 0 | Shift + 0 |
| YPbPr | YPbPr | OPT-TOOLS SETUP | Setup / OPT / |
| VIDEO | Video | SHIFT + VIDEO 4 | Shift + 4 |

| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| PC | PC | SHIFT + PC FAV MARKER | Shift + Fav / Marker / PC |
| Vol | CH+ | CH PAGE | CH+ / Page+ |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| CH | Vol + | VOL | Vol + |
| Vol | Vol - | VOL | Vol - |
| ZOOM | Zoom | SIZE ZOOM | Zoom / Size |
| CH | CH- | CH PAGE | CH- / Page- |
| DUAL | Dual | LANG I/II AUDIO | Audio / Lang I/II |
| AUDIO ADJ | ADJ Audio | TITLE SOUND | Sound / Title |
| VIDEO ADJ | ADJ Video | FORMAT PICTURE | Picture / Format |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| MENU /EXIT | Menu/Exit | HOME MENU | Menu / Home |
| MENU /EXIT | Menu/Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |

| Originalfernbedienung | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|
| Down | Down | Freeze | Pause / Step / Freeze |
| Info | Info / Angle | | |
| Red | Red / Netflix / Search | | |
| Green | Green / APP / Repeat | | |
| Yellow | Yellow / YouTube / Repeat | | |
| Blue | Blue / Prime Video / Random | | |
| Teletext | Text / Goto | | |
| Mix | Shift + Text / | | |
| Size | Shift + Zoom / | | |
| Subpage | >> / Tune+ | | |
| Index | Play / Slow | | |
| Subtitle | Subtitle / EQ | | |
| Hold | Stop / Hold | | |
| Reveal | << / Tune- | | |
| FAV | Fav / Marker / PC | | |
| CH-List | Smart / List | | |
| AD | Shift + Audio / Lang I/II | | |