Original		Replacement	
	Power		Power
	Source		AV
	TrackID		TV/R
	?/i - Manual		D. Menu
	3D		3D
	[+]		Format
	Digital / Analog		List
	Exit		Exit
	Scene		Pre Ch
	Internet / Video		Media
	I <<		I <<
	Pause		Pause
	>>I		>>I
	<<		<<
	Play		Play
	>>		>>
	Stop		Stop

Original		Replacement	
	Rec		Rec
	Sync Menu		Menu
	Home		Smart
	[i +] / [?]		Info
	Options		Options
	Guide		Guide
	Return/ Back		Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	1		1

Original		Replacement		Original	Replacement
2	2	LIST	2		
3	3		3		
4	4		4		
5	5	PROG	5		
6	6		6		
7	7		7		
8	8	SLEEP	8		
9	9		9		
0	0	MANU	0		
[≡]		T	Text		
[. . .]			Subt		
+	Vol +		Vol +		
−	Vol -		Vol -		
	Mut e		Mut e		
PROG +	Pr og/ CH+		Ch +		
− CH	Pr og/ CH-		Ch -		
AUDIO	Audi o		Dual		