Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	TV Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
iPod/USB	iPod/USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
ONLINE MUSIC	Online Music	HOME SMART	Smart
INTERNET RADIO	Internet Radio	APP MEDIA	Media
CH/PAGE	CH/Page+	+ CH	Ch +

Original		Replacement	
CH/PAGE	CH/Page-	CH –	Ch -
ECO	Eco	ECO 3D	3D
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
INFO	Info	DISPLAY INFO	Info
OPTION	Option	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
SETUP	Setup	TOP MENU MENU	Menu
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TUNE –	I<<<Tune-	I<<<	I<<<
►/II	Play	PLAY MODE ►	Play
►/II	Pause	II	Pause

Original		Replacement		Original	Replacement
TUNE+	>>I / Tune+	>>I	>>I		
1	Smart Select 1	SHIFT + 1	Shift + 1		
SMART 2	Smart Select 2	SHIFT + 2	Shift + 2		
SELECT 3	Smart Select 3	SHIFT + 3	Shift + 3		
4	Smart Select 4	SHIFT + 4	Shift + 4		
MOVIE	Green/Movie	B	Green		
MUSIC	Red/Music	A	Red		
GAME	Blue/Game	D	Blue		
PURE	Yellow/Pure	C	Yellow		

Original		Replacement	
POWER	Power		Power
SLEEP	Sleep	PROG SLEEP	Sleep
CBL/SAT	CBL/SAT	1	1
DVD	DVD	2	2
Blu-ray	Blu-ray	3	3
GAME	Game	4	4
AUX1	AUX1	5	5
MEDIA PLAYER	Media Player	6	6
TV AUDIO	TV Audio	7	7
AUX2	AUX2	8	8
TUNER	Tuner	9	9
iPod/USB	iPod/USB	-/-- GUIDE	Guide
CD	CD	0	0
Bluetooth	Bluetooth	FAV PRE-CH	Pre Ch
ONLINE MUSIC	Online Music	HOME SMART	Smart
INTERNET RADIO	Internet Radio	APP MEDIA	Media
CH / PAGE	CH/Page+	+ CH	Ch +

Original		Replacement	
CH / PAGE	CH/Page-	CH –	Ch -
VOLUME	Vol +	+ VOL	Vol +
VOLUME	Vol -	VOL –	Vol -
MUTE	Mute	MUTE	Mute
BACK	Back	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
TUNE –	I<<<Tune-		I<<
TUNE +	>>I/Tune+		>>I
	Play	PLAY MODE	Play
	Pause		Pause
1	Smart Select 1	SHIFT + 1	Shift + 1
SMART 2	Smart Select 2	SHIFT + 2	Shift + 2
SELECT – 3	Smart Select 3	SHIFT + 3	Shift + 3

Original	Replacement	Original	Replacement
4 Smart Select 4	SHIFT + 4 Shift + 4		