# Mandis shop

ENE001

| Original | Replacement |
|---|---|
| Power | Power |
| Mute | Mute |
| Movie | 1 |
| Music | 2 |
| Photo | 3 |
| Home | Smart |
| Disk | Menu |
| All Media | Media |
| Subtitle | Subt |
| Audio | Dual |
| Zoom | Eject |
| Info | Info |
| Copy Target | Pre Ch |
| Vol + | Vol + |
| Vol - | Vol - |
| P+ | Ch + |
| P- | Ch - |

| Original | Replacement |
|---|---|
| OK | Ok |
| Up | Up |
| Down | Down |
| Right | Right |
| Left | Left |
| Stop | Stop |
| Pause | Pause |
| << | << |
| >> | >> |
| I << | I << |
| >>I | >>I |
| Repeat | Text |
| Tv Out | TV/R |
| Setup | Options |
| A-B | D. Menu |
| BGM/Go to | Format |
| Slide Type | Guide |

https://remotes.net/Energy-Sistem/10628833-replacement-remote-control-for-Energy-Sistem-ENE001.htm