| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | Source | | AV / Input / RDS |
| | 1 | | 1 |
| | 2 | | 2 |
| | 3 | | 3 |
| | 4 | | 4 |
| | 5 | | 5 |
| | 6 | | 6 |
| | 7 | | 7 |
| | 8 | | 8 |
| | 9 | | 9 |
| | 0 | | 0 |
| | Mute | | Mute / Dimmer |
| | Guide | | Guide / EPG / -/-- |
| | Menu | | Menu / Home |
| | Smart Colors | | Smart / List |
| | Info | | Info / Angle |

| Original | | Replacement | |
|---|---|---|---|
| | Up | | Up |
| | Down | | Down |
| | Left | | Left |
| | Right | | Right |
| | OK | | OK |
| | Back | | Back / Return |
| | Home | | Shift + Menu / |
| | Exit | | Exit / Cancel / Clear |
| | Vol + | | Vol + |
| | Vol - | | Vol - |
| | CH+ | | CH+ / Page+ |
| | CH- | | CH- / Page- |
| | Netflix | | Shift + Red / Netflix / |
| | prime video | | Shift + Blue / Prime |
| | YouTube | | Shift + Yellow / YouTube / |
| | FPlay | | Shift + Green / APP / |
| | Audio | | Audio / Lang I/II |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| SUB | Sub | EQ SUBTITLE | Subtitle / EQ | | |
| TEXT | Text | GOTO TEXT | Text / Goto | | |
| TV | TV | PROGRAM TV/RADIO | TV/Radio / | | |
| ▶II | Play | SLOW ▶ | Play / Slow | | |
| ▶II | Pause | STEP-FREEZE II | Pause / Step / Freeze | | |
| ◀◀ | << | TUNE- ◀◀ | << / Tune- | | |
| ▶▶ | >> | TUNE+ ▶▶ | >> / Tune+ | | |
| ■ | Stop | HOLD ■ | Stop / Hold | | |
| | Red | NETFLIX SEARCH | Red / Netflix / Search | | |
| | Green | APP REPEAT | Green / APP / Repeat | | |
| | Yellow | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| | Blue | Prime Video RANDOM | Blue / Prime Video / Random | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |