Mandis shop

REMCON2119

Original		Replacement	
ON/OFF	On/Off		Power
Mode	Mode	FORMAT PICTURE	Picture / Format
Fan Speed	Fan Speed	LIST SMART	Smart / List
Up	+/Up	CH PAGE +	CH+ / Page+
Timer	Timer	TIMER SLEEP	Sleep / Timer
Down	-/Down	CH PAGE −	CH- / Page-

Original	Replacement

https://remotecontrols.at/en/1068077-96831-replacement-remote-control-for-REMCON2119.html