Mandis shop

RC-601

Original		Replacement		Original	Replacement
IN	IN		Up		
IN	IN	CH PAGE +	CH+ / Page+		
IN	IN		Right		
IN	IN	VOL +	Vol+		
OUT	OUT		Down		
OUT	OUT	CH PAGE −	CH- / Page-		
OUT	OUT		Left		
OUT	OUT	VOL −	Vol-		

https://remotecontrols.at/en/LAVA/1068113-27978-replacement-remote-control-for-LAVA-RC-601.html