Original		Replacement	
	Power		Power
	Mute		Mute
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	<<		<<
	>>		>>
	I <<		I <<
	>>I		>>I
	Play		Play
	Pause		Pause
	Stop		Stop
	Repeat		Shift + Text
	Subtitle		Subt
	TTX		Text
	Recall		Back

Original		Replacement	
	Audio		Dual
	Menu		Menu
	Info		Info
	Exit		Exit
	FAV		Pre Ch
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK		Ok
	First Nothing		Smart
	Second Nothing		Media
	Vol +		Vol +
	Vol -		Vol -
	CH+		Ch +
	CH-		Ch -
	1		1

Original		Replacement		Original	Replacement
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
GOTO	Got o	SETTINGS OPT	Opt i ons		
TV/RADIO	Tv/ Radi o	SEARCH TV/R	TV/ R		