Mandis shop

Denon RC-270

Original	Replacement
Power	Power
Prog/Direct	Sleep
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
10	0
+10	Guide
Call	Pre Ch
Play	Play
Pause	Pause
Stop	Stop

Original	Replacement
Rec	Rec
>>I	>>I
I<<	I<<
>>	>>
<<	<<
Time	AV
Clear	Exit
Enter	Ok
Title	Info
Character	Options
Edit	TV/R
Repeat 1/ALL	Text
Repeat A-B	D. Menu
Random	Media
Eject	Eject
Memory Rec	Format
Synchro Rec	3D

https://remotecontrols.at/en/Denon/1056900-86420-replacement-remote-control-for-Denon-RC-270-00D3990473003.html