Original	Replacement	Original	Replacement
Power	Power	V-	Vol -
Source	AV	P+	Ch +
1	1	P-	Ch -
2	2	[G]	Guide
3	3	i	Info
4	4	Back	Back
5	5	Exit	Exit
6	6	OK	Ok
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
TXT	Text	Netflix	Media
Lang	Dual	YouTube	Smart
Mute	Mute	Prime Video	Shift + Smart
Home	Menu	☼1	Format
V+	Vol +	Red	Red

Original		Replacement		Original		Replacement	
	Green	B	Green				
	Yellow	C	Yellow				
	Blue	D	Blue				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec	REC MODE	Rec				
	Play	PLAY MODE	Play				
	Stop		Stop				