Mandis shop

Panasonic 200094

Original		Replacement		Original		Replacement
POWER	POWER	Shift	+ Shift + Power			
POWER	POWER		Power			
MENU	INPUT NEXT	Source	Source			
SHUTTER SHUT	SHUT /	Video Comp	Comp / Video			
ASPECT	ASPECT	Aspect Eco	Eco / Aspect			
ZOOM + 6	D. ZOOM +	Play +	+ / Play			
D.ZOOM - 5	D. ZOOM -	Stop −	- / Stop			
PAGE UP	UP		Up			
PAGE DOWN	DOWN		Down			
	LEFT		Left			
	RIGHT		Right			
ENTER	ENTER	Enter	Enter			
AUTO SETUP	AUTO SETUP	Auto	Auto			
FREEZE	FREEZE	Timer Freeze	Freeze / Timer			
0 USER	USER	Mute Blank	Blank / Mute			
1 STD	STD	Mode	Mode			

https://remotecontrols.at/en/Panasonic/1061115-66200-replacement-remote-control-for-Panasonic-N2QAGB000024.html