Mandis shop

Pioneer CU-XC005

Original	Replacement	Original	Replacement
Direct Play (--	Red / Netflix / Search	Display Up	CH+ / Page+
Direct Play OC	Green / APP / Repeat	Power	Power
Direct Play Y	Yellow / YouTube / Repeat	Vol -	Vol -
Direct Play [*	Blue / Prime Video / Random	Vol +	Vol +
Menu	Menu / Home		
Sound	Sound / Title		
>>	>> / Tune+		
Timer	Sleep / Timer		
Cancel	Exit / Cancel / Clear		
I <<-	I << / Preset-		
Stop	Stop / Hold		
>>I +	>>I / Preset+		
Set	Setup / OPT /		
Display/Characte	Info / Angle		
<<	<< / Tune-		
AUX	7		
Display Down	CH- / Page-		

https://remotecontrols.at/en/Pioneer/10591-507-replacement-remote-control-for-Pioneer-CU-XC005-AC70.htm