Mandis shop

Sony RM-SC55

Original	Replacement
Power	Power
Sleep	Sleep / Timer
Display	Display / Media
Tuner Memory	Zoom / Size
Play Mode/Tuning Mode	TV/Radio /
Folder-	CH- / Page-
Repeat/FM	Picture / Format
Clock/Timer	Up
Clock/Timer Set	Down
Audio In	Audio / Lang I/II
CD	3
Band/Tuner	Shift + TV/Radio / Program
Function	D.Menu / Top
I<<-	I<< / Preset-
>>I / +	>>I / Preset+
<<-	<< / Tune-
>>-	>> / Tune+

Original	Replacement
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Clear	Exit / Cancel / Clear
EQ	Subtitle / EQ
Vol +	Vol +
Vol -	Vol -
Enter	OK
Disck Skip	Fav / Marker / PC
Folder+	CH+ / Page+

https://remotes.com/Sony-10550-757-replacement-remote-control-for-Sony-RM-SC55-A1696.htm